

MCFORM 085

TITLE:

DESCRIPTION:

INSTALLATION INSTRUCTION

2007 & UP JK FRONT & REAR GRAB HANDLES

DATE:

PART #:

DEC 14, 2011

684206



NOTE: IT IS EASIER TO REMOVE THE SOFT OR HARD TOP BEFORE INSTALLING THE FRONT JK GRAB HANDLES.

STEP 1:WHEN INSTALLING THE FRONT JK GRAB HANDLES, PLACE THE PADDED SIDE OF THE GRAB HANDLE ON TOP OF ROLL BAR AND ENSURE BUCKLES ARE FACING INTO THE VEHICLE AND HANDLE IN FACING DOWNWARD.



STEP 2: RUN THE STRAPS THROUGH THE BUCKLES AND PULL EACH ONE TIGHT AS YOU VELCRO IT IN PLACE.



STEP 3: WHEN INSTALLING THE REAR JK GRAB HANDLES, REMOVE THE (2) SCREWS USING A 10 MM SOCKET.



STEP 4: SCREW THE GRAB HANDLE INTO THE SLOTS USING A 10 MM SOCKET.

NOTE: BE SURE NOT TO OVER TIGHTEN SCREW DUE TO THE PLASTIC SPEAKER CASE CAN EASILY GET STRIPPED.